

## Leg motor

### 1. Removing the leg motor.

\* Using the leg massage leveler, set the leg massage.

1. Remove the Velcro (a) from the backside of the leg massage. Peel off the cover.
2. Pull up the foot rest (b).
3. Pull out the leg massage block 4 (50).
4. Unscrew (51), and dismantle.
5. Remove the connector (52), and change the leg motor.

