


Seat spring cushion

1. Removing the seat spring cushion

- Remove the seat cushion cover, and the seat spring cushion can be removed.


***Caution during installation.**

- When installing the eight seat spring b (28), they must be placed in the correct position as shown in the photo (rows 1, 3, 6 and 10). Please refer to the photo when installing.



(27) Seat spring cushion

(28) Seat spring B



(27) Seat spring cushion