

Electrical power switch block


1. Fuse change

1. Unscrew (57), and remove (59).
2. Unscrew the two (58), and remove the Electrical Power Switch Block.
3. Change fuse (61).

2. Controller cord change

1. Unscrew (57), and remove (59).
2. Pull out the controller cord (72) , and remove the connector.

Fuse change



Controller cord change

