

REPLACEMENT PARTS LIST

RMKS	REF.No.	PART No.	PARTS NAME / DESCRIPTIONS	QTY	NOTES
	101	WEP1010L2898	CONNECTING CORD FOR POWER SUPPLY	1	
	102	WEP1010L0598	COVER CLIP	1	
	103	WEP596L6627	SCREW(Cup.S.K4-6)	7	*1
	104	WEP755L2108	MAIM CIRCUIT BOARD W/COMPONENT	1	
	105	WEP755L9778	SCREW(Cup.S.K3-8)	4	*1
	106	WEP579L0031	SHIELD PANEL FOR P.C.B	1	
	107	WEP755L6338	SCREW(Sems.S.Hex.K4-10)	20	*1
	108	WEP579L1001	MOTOR	1	
	109	WEP596L0237	GUIDE PLATE FOR MOTOR	1	
	110	WEP596L1117	TAPPING BELT	1	
	111	WEP596L6087	SCREW(BIND.TP.B4-48)	3	*1
	112	WEP596L9137	SCREW(TP K4-14)	2	*1
	113	WEP596L0187	GROUND SPRING C	1	
	114	WEP596L1778	TAPPING GEAR BOX A B SET	1	
	115	WEP579L1490	TAPPING CLUTCH	1	
	116	WEP755L9537	SCREW(BIND.TP.B3-20)	1	
	117	WEP569L6857	E TYPE STOP RING	1	
	118	WEP596L5197	PLATE FOR TAPPING GEAR BOX	1	
	119	WEP569L1147	TAPPING BELT A	1	
	120	WEP579L4340	TAPPING SHAFT ASSEMBLY	1	
	121	WEP596L0208	PRO TEKTITE COVER FOR ECCENTRIC LINK	2	*1
	122	WEP596L6328	SCREW(Hex.S.K4-22)	2	*1
	123	WEP596L1127	INTENSITY ADJUSTMENT BELT	1	
	124	WEP569L1397	UP/DOWN DETECTOR GEAR A	1	
	125	WEP579L1840	SIDE COVER BLOCK	1	
	126	WEP589L2189	UP/DOWN DETECTOR P.C.B	1	
	127	WEP596L3417	UP/DOWN BELT	1	
	128	WEP596L0217	GUIDE PLATE FOR GEAR BOX	1	
	129	WEP589L6679	SCREW(TP.BH4-38P)	4	*1
	130	WEP596L6887	K TYPE STOP RING Ø15	1	
	131	WEP755L0508	INTENSITY ADJUSTMENT BLOCK	1	
	132	WEP755L0467	INTENSITY ADJUSTMENT PLATE	1	
	133	WEP589L4959	INTENSITY ADJUSTMENT P.C.B	1	
	134	WEP569L0577	INTENSITY NUT CASE	1	
	135	WEP579L2381	CAPACITOR	1	
	136	WEP589L6997	SCREW(TP BH4-60)	2	*1
	137	WEP589L6579	SCREW(TP BH4-58)	2	*1
	138	WEP596L1797	GEAR BOX B	1	
	139	WEP579L4840	UP/DOWN CLUTCH	1	
	140	WEP579L4830	MASSAGE CLUTCH	1	
	141	WEP570D4637	INTERMEDIATE GEAR BLOCK	1	
	142	WEP596L1767	GEAR BOX A	1	

RMKS: SPARE PARTS SUPPLIED FROM AROMAT IS MARKED ▲ AHEAD OF REF.No.

RMKS	REF.No.	PART No.	PARTS NAME / DESCRIPTIONS	QTY	NOTES
	143	WEP596L1097	MESSAGE BELT	1	
	144	WEP578L4357	DRIVE PIPE	1	
	145	WEP579L0378	UP/DOWN SHAFT	1	
	146	WEP579L1460	UP/DOWN GEAR	1	
	147	WEP578AL0317	RUBBER RING	2	*1
	148	WEP578AL1907	UP/DOWN SHAFT SPRING	1	
	149	WEP545H1917	GUIDE ROLLER A	1	
	150	WEP579L0830	SPACER FOR GUIDE ROLLER	1	
	151	WEP579L3530	FITTING	2	*1
	152	WEP596L6057	UP/DOWN SHAFT BOLT	2	*1
	153	WEP578L0167	FASTENING SPRING FOR SHAFT	2	*1
	154	WEP578L0387	SPRING COVER	2	*1
	155	WEP578L0197	SPRING	2	*1
	156	WEP755L1167	MESSAGE WHEEL UNIT (RIGHT)	1	
	157	WEP755L1177	MESSAGE WHEEL UNIT (LEFT)	1	
	158	WEP596L0637	ECCENTRIC SHAFT RING	1	
	159	WEP755L1187	MESSAGE WHEEL UNIT SET	1	
	160	WEP545H1937	GUIDE ROLLER B	1	
	161	WEP579L1440	PINION B BLOCK	1	
	162	WEP596L0327	PIPE	1	
	163	WEP569L0458	MESSAGE POSITION PLATE	1	
	164	WEP589L4949	MESSAGE POSITION DETECTOR P.C.B	1	
	165	WEP596L1957	GUIDE ROLLER F	2	*1
	166	WEP596L0287	COUPLING BAR	1	
	167	WEP579K9578	SCREW(CUP.S.K4-16)	4	*1
	168	WEP579L0558	MAIN FRAME	1	
	169	WEP1011L0530	MESSAGE MECHANISM COVER	1	
	170	WEP589L0218	CORD GUIDE PLATE	1	
	171	WEP579L6638	SCREW(SEMS.K4-8)	2	*1
	172	WEP573L2238	TRANSFORMER	1	
	173	WEP578L0288	BASE FOR TRANSFORMER	1	
	174	WEP578AL1307	PULLEY	1	
	175	WEP750L0167	SPRING WASHER GUIDE ROLLER	1	
	176	WEP567ED0177	GROUND SPRING B	2	*1
	177	WEP1010L2928	CONNECTING CORD FOR CONTROLLER	1	
	178	WEP755L4878	DRIVE PIPE ASSEMBLY	1	
	179	WEP578AL0487	CLIP (WE-3U)	2	*1
	180	WEP755L0218	FITTING	1	
	181	WEP578AL0497	CLIP (WWS-2U)	2	*1
	182	WEP005W8537	INSULATED TIE(MEDIUM T30R-SF)	1	
	183	WEP004W8517	INSULATED TIE(MEDIUM)	1	

NOTES: *1 Individual supply. *2 Supplied as set.