


ADJUSTMENTS

- If the massage mechanism is removed from the chair, the position of up/down detector gear may change and the up/down stop position will be changed. Adjust the up/down gear. Also, if chair has received sufficient shock

during transportation (I.E. dropped from more than 1 m), massage mechanism may jam at top position.

In this case, the controller will flash all indication lights several times and turn off.

■ HOW TO ADJUST THE DECLINE OF THE MESSAGE MECHANISM




1. Before setting the massage mechanism onto the chair back, keep pushing the controller pad (down ▼) until the massage mechanism stops.

NOTE: Do not touch the rotating part of the massage mechanism with your body (hand) or cloth.

2. Set the massage mechanism block onto the chair back and move up until it comes both right and left rail pieces by turning the nut of the up/down clutch with a box driver in parallel.
3. After adjusting the position, set the both left and right rail pieces with 4 screws.

■ HOW TO ADJUST THE POSITION OF THE UP/DOWN GEAR



4. Set the selector switch to level ①, and keep pushing the controller pad (up ▲) until the guide roller of the massage mechanism comes to the stop position as shown in figure.
5. The proper position for the guide roller is with clearance (A) of about 5 to 15 mm from bottom of the square opening.
6. If the massage mechanism is too high, turn the up/down detector gear clockwise to move it lower.
If the massage mechanism is too low, turn the up/down detector gear counter-clockwise to move it higher.

NOTE: Rotating the up/down detector gear changes the highest/lowest position of the massage mechanism about 4 mm/cog.

7. After adjusting the up/down gear, check the up/down position at rolling massage of the manual operation with setting the massage head adjustment switch to level ①.