

Service Manual

MESSAGE LOUNGER
EP1004

SPECIFICATIONS

Power source: 120V AC, 60Hz
Power consumption: 150 W

<Massage lounger>

Rotation speed (Massage head): Approx. 28 times/min

Massaging width: (Shoulder to Back) 2 11/64"-6 19/64"
(55-160mm)

(Back to Lower Back) 2 11/64"-3 15/64"
(55-100mm)

Tapping speed (One way): Approx. 500 times/min

Rolling massage: Approx. 1 cycle every 33 sec.

Rolling massage: 2 9/16"-3 15/16"(65-100mm)

Regional rolling massage: Approx. 4 23/32"(120mm)

Massage travel up and down from neck
and shoulder section to waist section: 21 2/1" (Approx. 565mm)

Massage heads adjustment: 7 steps

Massage heads extension: Approx. 1 3/16"(30mm)

Automatic shut-off timer: Approx. 15 min.

Programmed operation time: 12 - 14 min.

Short Program time : 5 - 6 min.

<Leg massager>

Speed: Approx. 3,200 rpm


Automatic shut-off timer: Approx. 30 min.

Maximum user weight: 264 lbs(120 kg)

Accessories: Back Cushion

Weight: 145 lbs (65.25 kg)

Dimensions: Not reclined and Leg Massager folded
45"(H) X 33 1/2"(W) X 35 2/1"(D)
1,143(H) X 851(W) X 902(D) mm
Reclined and Leg Massager extended
34 2/1"(H) X 33 1/2"(W) X 68 2/1"(D)
877(H) X 851(W) X 1,740(D) mm



CONTENTS

	Page
• Specifications	1
• Parts Indication & Control Panel..	2,3
• Basic Movement.....	4-6
• Schematic Diagram.....	7,8
• Wiring Connection Diagram.....	9
• Disassembly Instructions.....	10-20
• Adjustment.....	21
• Trouble Shooting Guide.....	22-26
• Exploded View.....	27,28
• Replacement Parts List.....	29-32
• Paking Instructions.....	33,34